

Sewlore stretch and recovery log

Enter original, stretched and released readings in one unit. Keep each reading greater than zero.

Stretch and residual use original length. Recovered extension uses stretched minus original.

[Sewlore measurement methods guide](#)

Amber cells are editable. Formula and worked-example cells are protected without a password.

Record the same marked span, unit, direction and method. Displayed decimals do not add measurement accuracy.

Record ID	Unit	Original	Stretched	Released	Extension (mm)	Stretch	Residual growth	Recovered extension	Record status	Method and timing notes

Worked examples: synthetic inputs for learning. No physical specimen or care process was tested.

Record ID	Unit	Original	Stretched	Released	Extension (mm)	Stretch	Residual growth	Recovered extension	Record status	Method and timing notes
EX-S1	mm	100.000	125.000	103.000	25.000	25.0%	3.0%	88.0%	Recorded	Synthetic software example
EX-S2	cm	10.000	10.000	10.000	0.000	0.0%	0.0% n.a.		Recovery undefined: zero extension	No entered extension
EX-S3	in	4.000	5.000	3.900	25.400	25.0%	-2.5%	110.0%	Review released reading	Signed result preserved
EX-S4	mm	100.000	125.000	130.000	25.000	25.0%	30.0%	-20.0%	Review released reading	Released exceeds stretched
EX-S5	cm	10.000	14.000	10.500	40.000	40.0%	5.0%	87.5%	Recorded	Synthetic software example

How to record

Record the actual extension method, endpoints, direction and interval between release and the released reading.

Recovery is n.a. when original equals stretched. Released outside the original–stretched span is flagged and remains signed.

Formulas: stretch=(S–O)/O. Residual=(R–O)/O. Recovered extension=(S–R)/(S–O).

Sewlore paired care measurement log

Enter paired dimensions from the same marked sample. These readings describe change after the recorded process.

Signed contraction: positive = contraction, negative = expansion. Area requires flat rectangular geometry.

[Sewlore measurement methods guide](#)

Amber cells are editable. Formula and worked-example cells are protected without a password.

Record the same marked span, unit, direction and method. Displayed decimals do not add measurement accuracy.

Record ID	Unit	Before length	Before width	After length	After width	Rectangle?	Length contraction	Width contraction	Area contraction	Record status	Care and method notes

Worked examples: synthetic inputs for learning. No physical specimen or care process was tested.

Record ID	Unit	Before length	Before width	After length	After width	Rectangle?	Length contraction	Width contraction	Area contraction	Record status	Care and method notes
EX-C1	cm	20.000	40.000	19.000	39.000	Yes	5.0%	2.5%	7.4%	Recorded	Synthetic software example
EX-C2	cm	20.000	40.000	22.000	38.000	Yes	-10.0%	5.0%	-4.5%	Recorded	Synthetic software example
EX-C3	mm	100.000	100.000	90.000	95.000	Yes	10.0%	5.0%	14.5%	Recorded	Synthetic software example
EX-C4	in	8.000	12.000	7.800	12.200	No	2.5%	-1.7%	n.a.	Sides recorded; area not calculated	Synthetic software example
EX-C5	cm	20.000	40.000	20.000	40.000	Yes	0.0%	0.0%	0.0%	Recorded	Synthetic software example

How to record

Record the care process actually used, settings, cycle count, marked endpoints and measurement conditions.

These arithmetic comparisons cannot predict shrinkage, prescribe care instructions or establish garment fit.

Formulas: side contraction=(before–after)/before. Area contraction=1–(after length/before length)×(after width/before width).

Sewlore Fabric Measurement Workbook 1.0.0

Original educational workbook by Sewlore. AI-assisted preparation. CC BY 4.0 for any applicable rights.

[Attribution: Sewlore, Fabric Measurement Workbook 1.0.0.](#)

Sewlore length unit conversion

Enter a value and select both units. Zero is permitted for conversion. Record source resolution in the notes.

Exact factors: 1 cm = 10 mm. 1 in = 25.4 mm. Calculations preserve the full value before display rounding.

[Sewlore measurement methods guide](#)

Amber cells are editable. Formula and worked-example cells are protected without a password.

Record the same marked span, unit, direction and method. Displayed decimals do not add measurement accuracy.

Record ID	Input value	From unit	To unit	Converted value	Record status	Reading notes

Worked examples: synthetic inputs for learning. No physical specimen or care process was tested.

Record ID	Input value	From unit	To unit	Converted value	Record status	Reading notes
EX-U1	1.000 in	mm		25.400 Converted		Synthetic arithmetic example
EX-U2	25.400 mm	in		1.000 Converted		Synthetic arithmetic example
EX-U3	10.000 cm	in		3.937 Converted		Synthetic arithmetic example
EX-U4	0.000 cm	mm		0.000 Converted		Synthetic arithmetic example
EX-U5	100.000 mm	cm		10.000 Converted		Synthetic arithmetic example

How to record

Conversion changes the unit, not the resolution or reliability of the original reading.

Use converted readings explicitly before entering paired comparisons. Each comparison row uses one common unit.

To extend the log, remove sheet protection, copy a complete blank row with formulas and validation, then restore protection.